

CAUTION

THERE ARE NO SERVICEABLE COMPONENTS INSIDE THE WIRED 5-BUTTON SWITCH

Description

The Wired 5-Button Switch is a SimplySNAP component installed anywhere you need to add push-button lighting control for a SimplySNAP system. It is ideal for SimplySNAP systems being used in multi-use facilities such as municipal ball parks, hockey arenas, basketball facilities, and other multi-use sports complexes.

The Wired 5-Button Switch switch connects to a SS420/450 site controller via the USB interface to make it easy to get manual access to site lighting controls.

This is ideal for an indoor application where the customer would like the option of controlling their lights by pressing a button rather than by logging into SimplySNAP.

Operation Instructions

The Wired 5-Button Switch contains 5 control buttons that change the light levels for all connected lights. The default behavior for the buttons (which are numbered using dots) from top to bottom are as follows:

1. 100% Light Level
2. 75% Light Level
3. 50% Light Level
4. 25% Light Level
5. Off

Product Specifications

Parameter	Value
Input Power	25 mA at 5V (via USB cable)
Operating Temperature	0°C to +45°C
Certifications	FCC/IC
Warranty	1 Year

6723 Odyssey Drive // Huntsville, AL 35806 (877)
982-7888 // Synapse-Wireless.com



FCC Declaration of Conformity

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instruction manual may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.